
iMate™
UNIVERSAL ADB TO USB ADAPTER
Supports all ADB devices
Mac™OS
Easily connects any
ADB device to USB-equipped
iMac or PC computer
GRIFFIN
READY for iMac

iMate™

UNIVERSAL ADB TO USB ADAPTER

FROM GRIFFIN TECHNOLOGY

The innovative iMate USB to ADB adapter allows users to easily connect their existing ADB peripherals to all iMacs, Macs, Powerbooks, and PCs with USB. The iMate is compatible with any ADB device including mice, keyboards, trackballs, trackpads, hardware dongles, and Applevision displays. The iMate is a simple and inexpensive solution for making the transition to USB as well as preserving your investment in ADB devices.

The iMate adapter uses the Apple built in drivers in boot mode therefore providing the utmost in compatibility for input devices such as mice and keyboards. The adapter uses our iMate driver which provides complete compatibility for dongles and devices with special ADB drivers and control panels. (Driver can be downloaded from griffintechnology.com)

COMPATIBLE WITH THESE ADB DEVICES*

- Keyboards
- Mice
- Trackballs
- Trackpads
- Bar Code Readers
- Dongles
- Applevision Displays

The iMate is also the ultimate cross platform compatibility device. With Windows support you can now use your existing Mac keyboards, mice, trackballs, and trackpads to control both a Mac and a PC.

FOR USE WITH

iMacs, Macs, Powerbooks and PCs with USB

- One iMate can support multiple devices
- Supports keyboard soft power on and off
- Successfully tested by Apple and major hardware manufacturers
- Built-in Activity LED

CE

6 85387 02001 0

GRIFFIN TECHNOLOGY

Griffin Technology Corporation
80 Fesslers Lane
Nashville, Tennessee 37210
support@griffintechnology.com
www.griffintechnology.com
Telephone 615.255.0990

*Dongles and custom drivers require the iMate Driver available at our website.

iMate™ is a trademark of Griffin Technology Corporation. Apple® and Macintosh® are registered trademarks of Apple Computer Inc. All other trademarks are the property of their respective owners.